


FIRST-TIME COMPUTER USER WORKBOOK



Parts of Your Computer and What They're Called

Desktop Computer



Parts of Your Computer and What They're Called

Laptop Computer

Monitor


Power Button

Mouse Button

Track Pad


Right-Click Button

Left-Click Button




Parts of Your Computer and What They're Called

Common Computer Icons




Power On/Off

found on monitors, desktops, and laptops, as well as some other electronic devices




Eject Symbol

usually found on laptop keyboards, sometimes desktops; used to eject media like CDs or DVDs



Enter/Return Symbol

found on all keyboards; goes to the next line of text and also acts as an affirmative command



Volume Control

found on most keyboards; L-R: mutes, decreases, and increases volume